


User Manual for Automatic Fish Feeder with Timer & LCD Display



Specifications

- Food tank capacity: 200ml
- Power supply: 2x AA battery (NOT included)
- Display: LCD
- Dimensions: 15cm x 11cm x 7,5cm



1. Time setting
2. Feeding times/winding number setting
3. Manual button
4. Up/+ button
5. Settings button
6. Down/- button
7. Power button
8. Battery indicator
9. The feeder turning indicator

Adjusting the feeder

Press the power button for 3 seconds to switch the feeder on or off. To set a clock, press the Settings button for 3 seconds and use the + and - buttons to adjust the hours. Press the Time setting button again and adjust the minutes. Once you set up the time, press the Settings button to save the current setting and exit.

To set the feeding time, press and hold the Settings button for 3 seconds, and then press it a couple of times until the first box under the clock starts flashing. Use the + and - buttons to adjust the feeding time, press the Settings button to change to minutes, and use the + and - buttons again to adjust the minutes. The next step is to adjust how many times the feeder will rotate the food tank. Adjust it also using the + and - buttons. Press the Settings button again to adjust the next feeding time the same way.

You can also press the Manual button and the food tank will start rotating and feed the fish. By long-pressing the + button for 5 seconds it will set the feeding time once at 8:00 and once in 20:00 hours. By long-pressing the - button for 5 seconds it will delete all settings.